
hombli

Smart Doorbell Chime Quick start





Das erweiterte deutsche Handbuch finden Sie unter:

Para el manual ampliado en español vaya a:

Ga voor de uitgebreide Nederlandse handleiding naar:

For the extended English manual go to:

www.hombli.com/manual-chime

1. Pairing the Chime to a Smart Doorbell:

- Plug the Chime into a wall socket
- Press the "Up" or "Down" button to select your favorite ringtone
- Long press the "Volume" button for 5 seconds until a sound is heard and the LED indicator starts flashing
- Press the "Ring" button on the Smart Doorbell to send a pairing signal to the Chime
 - The Chime will automatically play the selected ringtone when the pairing is successful

Note:

Pairing mode will only last for 5 seconds. Be sure to press the "Ring" button on the Smart Doorbell within 5 seconds in order to pair it with the Chime

2. Sound Volume Control

Select one of the four volume levels by pressing the "Volume" button multiple times. The Chime will automatically remember the selected volume level.

3. Change the ringtone

Press the "Up" or "Down" button to choose from 21 different ringtones and follow the pairing steps to synchronize the new ringtone with the Smart Doorbell.

4. Pairing two or more Smart Doorbells

Follow the pairing steps with the same Chime and another Smart Doorbell to pair two or more Smart Doorbells to single a Chime.

5. Pairing two or more Chimes

Follow the pairing steps with the same Smart Doorbell and another Chime to pair two or more Chimes to a single Smart Doorbell.

6. Reset

Press the "Down" button for 5 seconds to reset the Chime to default factory settings. The Chime is now disconnected from the Smart Doorhell

For questions about your Hombli device or the Hombli app go to: www.hombli.com/support

Or send an email to: support@hombli.com

Hombli © 2020 Is a brand of Avanca International B.V. Orionstraat 13-15

2516AS The Hague

+31 702 210 077