

POPP

Popp

Mold detector

SKU: POPE701202



Quickstart

This is a **secure Alarm Sensor for Europe**. To run this device please insert fresh **1 * 1/2 AA** batteries. Please make sure the internal battery is fully charged. Tripple clicking the tamper button includes (adds) and excludes (removes) the device. A click on the tamper witch will wake up the device. The device supports the Security S2 framework with unauthenticated network keys. Please follow the instructions on the central controller when including. The device also supports Smartstart. Please scan the QR code on the outlet cover of the device and your controller will add the device automatically when powered up.

What is Z-Wave?

Z-Wave is the international wireless protocol for communication in the Smart Home. This device is suited for use in the region mentioned in the Quickstart section.

Z-Wave ensures a reliable communication by reconfirming every message (**two-way communication**) and every mains powered node can act as a repeater for other nodes (**meshed network**) in case the receiver is not in direct wireless range of the transmitter.

This device and every other certified Z-Wave device can be **used together with any other certified Z-Wave device regardless of brand and origin** as long as both are suited for the same frequency range.

If a device supports **secure communication** it will communicate with other devices secure as long as this device provides the same or a higher level of security. Otherwise it will automatically turn into a lower level of security to maintain backward compatibility.

For more information about Z-Wave technology, devices, white papers etc. please refer to www.z-wave.info.



Product Description

This device measures the three air quality parameters temperature, humidity and dew point and reports them to a central controller. Beside this, the device can directly control groups of other Z-Wave devices on over- and undershooting a set temperature and/or humidity parameter. This can be used to establish control loops for temperature and humidity. The device wakes up every 4 minutes to measure the values and it will send unsolicited reports when values change. Additionally, the device will report all values on request.

The mold detector is actively monitoring the danger of mold in a room based on the temperature and humidity and will issue alarm warnings when critical air conditions met. Wireless Alarm and red and a green blinking LED will indicate a mold condition. This local LED warning function is also available when the device is not included in any Z-Wave network and works stand alone.

Prepare for Installation / Reset

Please read the user manual before installing the product.

In order to include (add) a Z-Wave device to a network it **must be in factory default state**. Please make sure to reset the device into factory default. You can do this by performing an Exclusion operation as described below in the manual. Every Z-Wave controller is able to perform this operation however it is recommended to use the primary controller of the previous network to make sure the very device is excluded properly from this network.

Reset to factory default

This device also allows to be reset without any involvement of a Z-Wave controller. This procedure should only be used when the primary controller is inoperable.

Once Cover is removed and tamper switch is tripped, push the tamper for 5 seconds until red LED blinks. Then release tamper and push it again for 5 seconds until LED blinks.

Safety Warning for Batteries

The product contains batteries. Please remove the batteries when the device is not used. Do not mix batteries of different charging level or different brands.

Installation

The POPP Mold Detector can be mounted in two ways.

1. use the enclosed adhesive tape. Clean the substrate carefully from grease and dirt to achieve optimum strength of the adhesive areas.
2. use the enclosed screws and dowels to fix it to the wall or other surface.

Inclusion/Exclusion

On factory default the device does not belong to any Z-Wave network. The device needs to be **added to an existing wireless network** to communicate with the devices of this network. This process is called **Inclusion**.

Devices can also be removed from a network. This process is called **Exclusion**. Both processes are initiated by the primary controller of the Z-Wave network. This controller is turned into exclusion respective inclusion mode. Inclusion and Exclusion is then performed doing a special manual action right on the device.

Inclusion

Tripple clicking the tamper button includes (adds) the device.


Exclusion

Tripple clicking the tamper button excludes (removes) the device.

Product Usage


Open the POPP Mold Detector

To open the POPP Mold Detector, press the lock with your finger and pull the housing cover upwards.



Tamper button

The tamper button is located on the side of the POPP Mold Detector. This button is also used for inclusion and exclusion.



Functionality

Once the device is powered up it will start monitoring the air parameters and warn of mold using the local red and green LED. All air parameters are measured every 4 minutes. Pushing the button will force an immediate measurement and the LEDs will indicate the danger of mold

- green: no danger of mold in the room
- red: danger of mold, on the windows to lower the humidity

The device contains three sensors with the following accuracy measures:

- Humidity: +/- 3 % on relative humidity, +/-1 % hysteresis
- Temperature: 0 ... 65 °C +/- 1 Kelvin
- Dew Point: 0 ... 65 °C +/- 1 Kelvin (calculated from other sensor values)

Besides the measured values the device will issue Z-Wave notifications on moisture (0x10).

Node Information Frame

The Node Information Frame (NIF) is the business card of a Z-Wave device. It contains information about the device type and the technical capabilities. The inclusion and exclusion of the device is confirmed by sending out a Node Information Frame. Beside this it may be needed for certain network operations to send out a Node Information Frame. To issue a NIF execute the following action: Tripple Click the tamper button

Communication to a Sleeping device (Wakeup)

This device is battery operated and turned into deep sleep state most of the time to save battery life time. Communication with the device is limited. In order to communicate with the device, a static controller **C** is needed in the network. This controller will maintain a mailbox for the battery operated devices and

store commands that can not be received during deep sleep state. Without such a controller, communication may become impossible and/or the battery life time is significantly decreased.

This device will wakeup regularly and announce the wakeup state by sending out a so called Wakeup Notification. The controller can then empty the mailbox. Therefore, the device needs to be configured with the desired wakeup interval and the node ID of the controller. If the device was included by a static controller this controller will usually perform all necessary configurations. The wakeup interval is a tradeoff between maximal battery life time and the desired responses of the device. To wakeup the device please perform the following action: A single click on the tamper button will wakeup the device.

Quick trouble shooting

Here are a few hints for network installation if things dont work as expected.

1. Make sure a device is in factory reset state before including. In doubt exclude before include.
2. If inclusion still fails, check if both devices use the same frequency.
3. Remove all dead devices from associations. Otherwise you will see severe delays.
4. Never use sleeping battery devices without a central controller.
5. Dont poll FLIRS devices.
6. Make sure to have enough mains powered device to benefit from the meshing

Association - one device controls an other device

Z-Wave devices control other Z-Wave devices. The relationship between one device controlling another device is called association. In order to control a different device, the controlling device needs to maintain a list of devices that will receive controlling commands. These lists are called association groups and they are always related to certain events (e.g. button pressed, sensor triggers, ...). In case the event happens all devices stored in the respective association group will receive the same wireless command wireless command, typically a 'Basic Set' Command.

Association Groups:

Group Number	Maximum Nodes	Description
1	5	Lifeline
2	5	Temperature High Trigger
3	5	Temperature Low Trigger
4	5	Humidity High Trigger
5	5	Humidity Low Trigger

Configuration Parameters

Z-Wave products are supposed to work out of the box after inclusion, however certain configuration can adapt the function better to user needs or unlock further enhanced features.

IMPORTANT: Controllers may only allow configuring signed values. In order to set values in the range 128 ... 255 the value sent in the application shall be the desired value minus 256. For example: To set a parameter to 200 it may be needed to set a value of 200 minus 256 = minus 56. In case of a two byte value the same logic applies: Values greater than 32768 may needed to be given as negative values too.

Parameter 1: Minimum Temperature change to report

This value defines the minimum change of temperature to cause an unsolicited report of humidity to the central controller using Lifeline.

If the value is set to 0, there will be no reports sent to the controller, when the temperature changes. However, periodic reports, managed by configuration parameter 4, may still be active.

Size: 1 Byte, Default Value: 20

Setting	Description
1 - 100	1/10 degree
0	disabled

Parameter 2: Minimum humidity change to report

This value defines the minimum change of humidity to cause an unsolicited report of humidity to the central controller using Lifeline.

If the value is set to 0, there will be no reports sent to the controller, when the humidity changes. However, periodic reports, managed by configuration parameter 4, may still be active.

Size: 1 Byte, Default Value: 7

Setting	Description
1 - 20	%
0	disabled

Parameter 4: Periodic Reports

This parameter defines the time interval to send an unsolicited report.

If the value is set to 0, there will be no periodic reports sent to the controller. However, reports on temperature/humidity changes, managed by configuration parameters 1 and 2, may still be active.

Size: 2 Byte, Default Value: 43200

Setting	Description
---------	-------------

1 - 65535	Seconds
0	disabled

Parameter 5: Temperature Upper Watermark value

This parameter defines a temperature. If the measured temperature surpasses this watermark a BASIC command is sent into Association Group 2
Size: 2 Byte, Default Value: 0

Setting	Description
1 - 1000	1/10 degree
0	disabled

Parameter 6: Temperature Lower Watermark value

This parameter defines a temperature. If the measured temperature dropps below this watermark a BASIC command is sent into Association Group 3
Size: 2 Byte, Default Value:

Setting	Description
-200 - 1000	1/10 degree
0	disabled

Parameter 7: Humidity Upper Watermark value

This parameter defines a relative humidity. If the measured relative humidity surpasses this watermark a BASIC command is sent into Association Group 4
Size: 1 Byte, Default Value: 0

Setting	Description
10 - 100	%
0	disabled

Parameter 8: Humidity Lower Watermark value

This parameter defines a relative humidity. If the measured temperature dropps below this relative humidity a BASIC command is sent into Association Group 5
Size: 1 Byte, Default Value:

Setting	Description
1 - 90	%
0	disabled

Parameter 9: Low Temperature Trigger BASIC Set Command Value

This defines what BASIC command shall be sent out into association group 3
Size: 1 Byte, Default Value: 255

Setting	Description
0 - 255	Value

Parameter 10: High Temperature Trigger BASIC Set Command Value

This defines what BASIC command shall be sent out into association group 2
Size: 1 Byte, Default Value: 0

Setting	Description
0 - 255	Value

Parameter 11: Low Humidity Trigger BASIC Set Command Value

This defines what BASIC command shall be sent out into association group 5
Size: 1 Byte, Default Value: 255

Setting	Description
0 - 255	Value

Parameter 12: High Humidity Trigger BASIC Set Command Value

This defines what BASIC command shall be sent out into association group 4
Size: 1 Byte, Default Value: 0

Setting	Description
0 - 255	Value

Technical Data

Dimensions	25x25x10 mm
------------	-------------

Weight	11.73 gr
Hardware Platform	ZM5101
EAN	4251295701202
IP Class	IP 20
Voltage	3V
Battery Type	1 * 1/2 AA
Device Type	Notification Sensor
Generic Device Class	Notification Sensor
Specific Device Class	Routing Notification Sensor
Firmware Version	01.00
Z-Wave Version	06.02
Z-Wave Product Id	0x0154.0x0004.0x0014

Supported Command Classes

- Basic
- Sensor Binary
- Sensor Multilevel
- Association Grp Info
- Device Reset Locally
- Zwaveplus Info
- Supervision
- Configuration
- Alarm
- Manufacturer Specific
- Powerlevel
- Firmware Update Md
- Battery
- Wake Up
- Association
- Multi Channel Association
- Version
- Transport Service
- Security 2

Controlled Command Classes

- Transport Service
- Security 2

Explanation of Z-Wave specific terms

- **Controller** — is a Z-Wave device with capabilities to manage the network. Controllers are typically Gateways, Remote Controls or battery operated wall controllers.
- **Slave** — is a Z-Wave device without capabilities to manage the network. Slaves can be sensors, actuators and even remote controls.
- **Primary Controller** — is the central organizer of the network. It must be a controller. There can be only one primary controller in a Z-Wave network.
- **Inclusion** — is the process of adding new Z-Wave devices into a network.
- **Exclusion** — is the process of removing Z-Wave devices from the network.
- **Association** — is a control relationship between a controlling device and a controlled device.

- **Wakeup Notification** — is a special wireless message issued by a Z-Wave device to announces that is able to communicate.
- **Node Information Frame** — is a special wireless message issued by a Z-Wave device to announce its capabilities and functions.